### **CAUTION-**VAPOR HARMFUL. SEE OTHER CAUTIONS ON BACK PANEL.



## **United 96**

# **ANABONDA**

Industrial, Flexible, Waterproof Adhesive

Sold By:
UNITED LABORATORIES, INC.

320 37th Avenue • St. Charles, IL 60174 USA 1-800-323-2594 • www.unitedlabsinc.com

3.7 fl. oz. (109.4 mL)

**CAUTION:** Contains perchloroethylene. Intentional misuse by deliberately concentrating and inhaling the contents may be harmful.

WARNING: This product contains a chemical known to the state of California to cause cancer. Harmful if inhaled or swallowed. May cause dizziness, headache or nausea. Can cause skin and eye irritation. Exposure may cause damage to the kidneys or liver. Cancer agent based on experimental data. Keep away from heat and flame. Contact with flame or hot surface may cause toxic gases. Use only with adequate ventilation. To avoid breathing vapor, open all windows and doors to assure fresh air movement during application and drying. When using do not eat, drink or smoke. Avoid prolonged or repeated contact with skin. Wash thoroughly after handling.

FIRST AID: If you experience difficulty in breathing, leave the area to obtain fresh air. If continued difficulty is experienced, get medical assistance immediately. If swallowed, do not induce vomiting; get medical assistance. In case of eye contact, immediately flush eye with plenty of water for at least 15 minutes. For further health information, contact a poison control center.

### KEEP OUT OF REACH OF CHILDREN

#### DIRECTIONS FOR USE:

- Surface should be clean, dry and free of dirt. For best results, roughen surface before use.
- Use in a well-ventilated area.
- 3. Puncture seal in neck of tube using pointer cap.
- 4. Test small area before full use.
- Best when used between 70 and 85 °F / 21 and 29 °C.
- For non-porous surfaces, apply a thin coat to each surface. Wait approximately 2 minutes and press surfaces together.
- 7. For maximum-strength bond allow 24-72 hours for dry time.
- Clean uncured adhesive with acetone or citrus-based solvents. Cured material may be removed by cutting or scraping.
- To ensure easy cap removal, apply a thin coat of petroleum jelly to the threads of the tube before replacing the cap.

NOTE: May damage finished surfaces. Avoid such contact until completely dry. Not recommended for use on polystyrene, polyethylene, polypropylene, Styrofoam™ or paper products. Not recommended for any items that come into contact with food, drinking water or animals. Do not dry clean.

An MSDS for this product is available through United's website, www.unitedlabsinc.com, providing 24 hour access. Please read the MSDS carefully and follow all directions when using or handling this product.

HMIS® III CODE 0=MINIMAL 1 = SUGHT 2=MODERATE 3=SERIOUS 4=SEVERE PERSONAL PROTECTION INDEX Gloves and Goggles	HEALTH	*3
	FLAMMABILITY	0
	PHYSICAL HAZARD	1
	PERSONAL PROTECTION	n&p

\* = CHRONIC

Made in U.S.A.

0303400A 11aw10