

UNITED

L A B O R A T O R I E S

United 224

- An easy-to-use air conditioning condensate pan treatment.
- Particularly simple to dose in tight areas... drop in a couple **CHILL PILLS** and you're chillin'.
- Economical treatment lasts up to 30 days—longer in areas of low humidity.
- Helps control the build-up of scale, sludge and other accumulations in moist pans.
- Prevents overflows by eliminating plugged drain pans and tubes.
- Reduces odors.
- Completely soluble and deposit-free.

DIRECTIONS FOR USE:

For condensate drain pans, use two **CHILL PILLS** per three tons of cooling capacity on initial application, and then one or two tablets every month in subsequent treatments as needed or when you change the filter.

When possible, position **CHILL PILLS** so condensate moisture drips over them.

HMIS® III CODE: 0=MINIMAL 1=SLIGHT 2=MODERATE 3=SERIOUS 4=SEVERE PERSONAL PROTECTION INDEX: Glasses and Gloves	HEALTH	2
	FLAMMABILITY	0
	PHYSICAL HAZARD	0
	PERSONAL PROTECTION	B

CHILL PILLS A/C Overflow Pan Tabs

KEEP OUT OF REACH OF CHILDREN.

CAUTION

SEE SIDE PANEL FOR ADDITIONAL
PRECAUTIONARY STATEMENTS.

PRECAUCION AL USUARIO:

Si usted no puede leer Ingles, pregunte a alguien que le traduzca esta etiqueta para usted antes de uso.

UNITED LABORATORIES, INC.
320 37th Avenue • St. Charles, IL 60174
1-800-323-2594 • www.unitedlabsinc.com

CAUTION:

Contains Quaternary Ammonium Compounds (CAS# 1733-96-6). Do not take internally.

EMERGENCY AND FIRST AID PROCEDURES:

EYES: Flush with plenty of cool water for at least 15 minutes while holding eyelids open. Call a physician or poison control center immediately.

SKIN: Wash hands and face with soap and water. If irritation persists, call a physician or poison control center.

INHALATION: Remove to fresh air. If irritation persists, call a physician or poison control center.

IF SWALLOWED: DO NOT induce vomiting. If conscious, drink large quantities of milk, egg whites, gelatin solution or water. Avoid alcohol. Call a physician or poison control center immediately.

An MSDS for this product is available through United's website, www.unitedlabsinc.com, providing 24 hour access. Please read the MSDS carefully and follow all directions when using or handling this product. Never reuse empty containers. Incompatible materials may adversely react.

Manufactured and Printed in U.S.A.

104