

LABORATORIES

**RED-W Water Condensate Gel Tabs** are specially formulated to provide up to 6 months of effective protection for A/C

condensate drains and pans. The continuous, slow-release action cleans and prevents bio-film from forming in drain pains, while eliminating foul musty odors.

The gel tabs lock into place when activated by condensate moisture, so they stay put and do not block drains. When **RÉD-W** completely disappears from your drain pan, you know it is time to replace. It leaves nothing to remove or throw away.

One gel tab treats units up to 15 tons for 6 months. Approved for computer rooms.

## **DIRECTIONS:**

For systems up to 15 tons, place one **RED-W** gel tab in condensate pan, positioning it so condensing moisture drips onto, or runs over it. This locks the gel tab in place and begins to release its slow-release actives for effective cleaning performance. For larger systems use additional gel tabs.

United 225

**RED-W Water Condensate Gel Tabs** 

KEEP OUT OF REACH OF CHILDREN. **CAUTION** 

SEE SIDE PANEL FOR ADDITIONAL PRECAUTIONARY STATEMENTS.

PRECAUCION AL USARIO: Si usted no puede leer Ingles, pregunte a alguien que le traduzca esta etiqueta para usted antes de uso.

**Sold Exclusively By:** UNITED LABORATORIES, INC. 320 37th Avenue • St. Charles, IL 60174 1-800-323-2594 • www.unitedlabsinc.com Precautionary Statements: Not to be used in potable water. Harmful if swallowed, do not ingest. Avoid contact with skin and eyes.

## **EMERGENCY AND** FIRST AID PROCEDURES:

**EYES:** Flush with plenty of cool water for at least 15 minutes while holding eyelids open. Get prompt medical attention.

**SKIN:** Wash with soap and water. If irritation develops and persists, seek medical attention.

**INHALATION:** No adverse effects expected. But if breathing is difficult, remove to fresh air and get medical attention.

**INGESTION:** DO NOT induce vomiting. Never give anything by mouth to an unconscious person. If conscious, drink large quantities of water. Get medical attention immediately.

An MSDS for this product is available through United's website, www.unitedlabsinc.com, providing 24 hour access. Please read the MSDS carefully and follow all directions when using or handling this product. Never reuse empty containers. Incompatible materials may adversely react.

| ,  |                     |   |
|--|---------------------|---|
| HMIS® III CODE: 0=MINIMAL 1=SLIGHT 2=MODERATE 3=SERIOUS 4=SEVERE PERSONAL PROTECTION INDEX: Glasses and Gloves | HEALTH              | 1 |
|  | FLAMMABILITY        | 0 |
|  | PHYSICAL HAZARD     | 0 |
|  | PERSONAL PROTECTION | В |