

LABORATORIES

GENERAL INFORMATION:

United 266 Earth Smart® Chiller Coil Cleaner utilizes a high foaming formulation for cleaning chiller and evaporator coils of efficiency robbing particles. Because United 266 "rinses automatically" with the natural condensation action on these coils, it can be used to clean coils in place with no messy rinse.

United 266 is:

- Bio-based Formulated with surfactants on the EPA's Cleanaredients list.
- Farth Smart® certified to be safer in use and safer for the environment.
- Phosphate-free
 NPE-free
- VOC-free
- Non-butyl

DIRECTIONS FOR USE:

- 1. Dilute one part United 266 with three parts water and spray directly into finned coils making certain United 266 penetrates to all areas. United's A199 Stainless Steel Atomizer, A042 2 Gallon Compression Sprayer, or A078 Foamatic Trigger Sprayer are recommended to apply United 266.
- 2. Put unit back into service to create condensation on chiller coils and fins which will carry United 266 and dissolved soils down into condensation pan and drain. For faster cleaning, United 266 may be rinsed if desired, after allowing at least five minutes penetration of soils and binders on coils and fins.

For cleaning of permanent-type filters, use one part United 266 and three parts water in dip tank. After cleaning, rinse filters in clear water. For use as a filter adhesive, dip or spray undiluted United 266 onto filter. United 266 protects metal frames as well as filters by preventing corrosion.



Earth Smart® **Chiller Coil** Cleaner

KEEP OUT OF REACH OF CHILDREN. **CAUTION**

SEE SIDE PANEL FOR ADDITIONAL PRECAUTIONARY STATEMENTS.

PRECAUCION AL USARIO:

Si usted no puede leer Ingles, pregunte a alguien que le traduzca esta etiqueta para usted antes de uso.

Manufactured and Sold Exclusively By: UNITED LABORATORIES, INC. 320 37th Avenue • St. Charles, IL 60174 1-800-323-2594 • www.unitedlabsinc.com

CAUTION:

Contains Sodium silicate (CAS # 1344-09-8). Prolonged skin contact may cause irritation. Eye contact may cause irritation and prolonged eye contact may cause damage to tissues.

EMERGENCY AND FIRST AID PROCEDURES:

EYES: Immediately flush with plenty of water for at least 15 minutes while holding eyelids open. Seek medical attention immediately.

SKIN: Remove contaminated clothing. Wash with soap and plenty of water. If irritation persists, seek medical attention.

INHALATION: Remove to fresh air. If symptoms develop, seek medical attention. If not breathing, give artificial respiration.

INGESTION: DO NOT induce vomiting. If conscious, give cold water to dilute the product. Never give anything by mouth to an unconscious person. Seek medical attention immediately.

An MSDS for this product is available through United's website, www.unitedlabsinc.com, providing 24 hour access. Please read the MSDS carefully and follow all directions when using or handling this product. Never reuse empty containers. Incompatible materials may adversely react.

HMIS® III CODE: 0=MINIMAL 1=SLIGHT 2=MODERATE 3=SERIOUS 4=SEVERE PERSONAL PROTECTION INDEX: Glasses and Gloves	HEALTH	1
	FLAMMABILITY	0
	PHYSICAL HAZARD	0
	PERSONAL PROTECTION	В

311