

UNITED

LABORATORIES

GENERAL INFORMATION:

Closed System Concentrate is formulated for corrosion and scale control in closed loop heating and cooling systems.

- Protects both ferrous and non-ferrous metals
- Non-Phosphate, Non-Chromate

DIRECTIONS FOR USE:

For initial treatment, add 1 gallon of **Closed System Concentrate** for each 700 gallons in the system.

This is most easily done with a pot feeder or a Force-and-Suction pump. If using a pot feeder larger than the required dose, top up the chamber with water to prevent air from entering the system.

After running for 48 hours, test a sample of water for molybdate, a level in the range of 30-50 ppm is desired. Thereafter, a level check every 90 days is sufficient unless known leaks exist or there is some other loss of water from the system.

HMS® III CODE: 0=MINIMAL 1=SLIGHT 2=MODERATE 3=SERIOUS 4=SEVERE PERSONAL PROTECTION INDEX: Gloves and Goggles	HEALTH	3
	FLAMMABILITY	0
	PHYSICAL HAZARD	0
	PERSONAL PROTECTION	n&p

United 420

Closed System Concentrate

KEEP OUT OF REACH OF CHILDREN.

CAUTION

HARMFUL OR FATAL IF SWALLOWED.

SEE SIDE PANEL FOR ADDITIONAL PRECAUTIONARY STATEMENTS.

PRECAUCION AL USUARIO:

Si usted no puede leer Ingles, pregunte a alguien que le traduzca esta etiqueta para usted antes de uso.

Manufactured and Sold Exclusively By:
UNITED LABORATORIES, INC.

320 37th Avenue • St. Charles, IL 60174
1-800-323-2594 • www.unitedlabsinc.com

CAUTION:

Contains sodium nitrite and concentrated alkali. Can cause burns to skin and eyes. Highly toxic. Do not take internally. **HARMFUL OR FATAL IF SWALLOWED.**

EMERGENCY AND FIRST AID PROCEDURES:

EYES: Immediately flush with plenty of water for at least 15 minutes while holding eyelids open. Call a physician immediately.

SKIN: Wash with soap and water. If irritation persists, call a physician.

INHALATION: Remove to fresh air. Apply CPR as necessary and call a physician immediately.

IF SWALLOWED: If conscious, give large amounts of water then induce vomiting by touching back of throat with finger. Keep head below hips to prevent aspiration of liquid into lungs. Call a physician immediately.

An MSDS for this product is available through United's website, www.unitedlabsinc.com, providing 24 hour access. Please read the MSDS carefully and follow all directions when using or handling this product. Never reuse empty containers. Incompatible materials may adversely react.