



# UNITED

LABORATORIES

## United 28

# AIR LOCK Urinal and Drain Treatment

**AIR LOCK Urinal and Drain Treatment** is a bio-based and biodegradable treatment for use in waterless urinals and drains. **AIR LOCK** floats on urine, water and other liquids in drains and urinal traps to effectively lock out the air that creates and carries the odors out of the drain, while creating a safe barrier between the user and the fluids in the drains.

### AIR LOCK:

- Earth Smart® Certified;
- Floats on water, urine and other liquids;
- Locks air out and sewer odors in;
- Will not evaporate to 100°F;
- Will not freeze above -14°F;
- Features Cucumber Melon scent.

### DIRECTIONS FOR USE:

**WATERLESS URINALS:** Simply pour 3 ounces of **AIR LOCK** directly into holes of trap to fill filter cartridge. Refill as needed. Each 3 ounce application lasts for approximately 1,500 uses.

**DRAINS:** Depending on drain size, add 3 to 5 ounces of product to create a layer across the top of the fluid in the drain. Re-application will vary depending on drain flow. Replace when layer is noticeably deteriorated or odors begin to return.

**KEEP OUT OF REACH OF CHILDREN.**

## CAUTION

**SEE SIDE PANEL FOR ADDITIONAL PRECAUTIONARY STATEMENTS.**

### PRECAUCION AL USUARIO:

*Si usted no puede leer Ingles, pregunte a alguien que le traduzca esta etiqueta para usted antes de uso.*

**Manufactured and Sold Exclusively By:**  
**UNITED LABORATORIES, INC.**  
320 37th Avenue • St. Charles, IL 60174  
1-800-323-2594 • [www.unitedlabsinc.com](http://www.unitedlabsinc.com)

**NOTE:** Do not subject this product to disinfectants, boiling water, or chlorinated products.

### EMERGENCY AND FIRST AID PROCEDURES

**EYES:** Flush with plenty of water for at least 15 minutes. If irritation persists, seek medical attention.

**SKIN:** Wash with soap and plenty of water.

**INHALATION:** Remove patient to fresh air. If symptoms persist, seek medical attention.

**INGESTION:** Give one or two glasses of water to drink. DO NOT induce vomiting. If gastrointestinal symptoms develop, get medical attention. Never give anything by mouth to an unconscious person.

An MSDS for this product is available through United's website, [www.unitedlabsinc.com](http://www.unitedlabsinc.com), providing 24 hour access. Please read the MSDS carefully and follow all directions when using or handling this product. Never reuse empty containers. Incompatible materials may adversely react.

<b>HMIS® III CODE:</b> 0=MINIMAL 1=SLIGHT 2=MODERATE 3=SERIOUS 4=SEVERE <b>PERSONAL PROTECTION INDEX:</b> Glasses and Gloves	HEALTH	1
	FLAMMABILITY	1
	PHYSICAL HAZARD	0
	PERSONAL PROTECTION	B