

UNITED

L A B O R A T O R I E S

Excellent for:

- X-RAY developing process and photo and film developing process to keep pipes and drains running free.

DIRECTIONS:

Remove all standing water from drain. If available, use a kitchen baster to draw additional water out of drain to make room in the drain for the chemical. This will serve to put the chemical in closer contact with the blockage. Pour in 4 to 8 ounces (120-240 mL) of **X-RAY Drain Pipe Opener**. Let stand for five to ten minutes, and then add one cup (240 mL) of cool water, slowly. Add additional water slowly, and when it is determined the drain is open, turn on the hot water faucet and give the drain a three to five minute flush with as hot a water as is available.

It is recommended this product be used in a regular weekly maintenance program. For best results add at least 10 to 12 ounces weekly. Some drains may require more **X-RAY** depending on drain activity.

HMIS® III CODE: 0=MINIMAL 1=SLIGHT 2=MODERATE 3=SERIOUS 4=SEVERE PERSONAL PROTECTION INDEX: Gloves and Goggles	HEALTH	3
	FLAMMABILITY	0
	PHYSICAL HAZARD	2
	PERSONAL PROTECTION	n&p

United 499

X-RAY Drain Pipe Opener

KEEP OUT OF REACH OF CHILDREN.



SEE SIDE PANEL FOR ADDITIONAL PRECAUTIONARY STATEMENTS.

PRECAUCION AL USUARIO:

Si usted no puede leer Ingles, pregunte a alguien que le traduzca esta etiqueta para usted antes de uso.

Manufactured and Sold Exclusively By:
UNITED LABORATORIES, INC.
320 37th Avenue • St. Charles, IL 60174
1-800-323-2594 • www.unitedlabsinc.com

DANGER – POISON

HARMFUL OR FATAL IF SWALLOWED. CAUSES SEVERE BURNS. NEVER ADD THIS PRODUCT TO DRAINS IN WHICH OTHER DRAIN CLEANERS HAVE BEEN USED. CAN CAUSE DANGEROUS CHEMICAL REACTIONS.

Contains concentrated solution of Potassium Hydroxide (CAS # 1310-58-3). Wear rubber gloves and eye protection when using or handling this product. Will cause severe burns on contact with eyes or skin. Harmful to shoes and fabrics.

EMERGENCY AND FIRST AID PROCEDURES:

EYES: Immediately flush eyes with large amounts of water for at least 15 minutes while holding upper and lower lids open to ensure flushing of the entire surface. Tilt head to avoid contaminating unaffected eye. Get medical attention immediately.

SKIN: Immediately wash contaminated areas with plenty of water for 15 minutes while removing contaminated clothing and shoes. Get medical attention immediately. Do not reuse clothing until cleaned and discard footwear which can not be decontaminated. Do not apply oils or ointments unless ordered by the physician. If skin feels slippery, caustic may still be present in sufficient quantities to cause rash or burn.

INHALATION: Remove to fresh air; if breathing is difficult, have a trained person administer oxygen. Get medical attention immediately. If breathing stops, give CPR.

INGESTION: DO NOT INDUCE VOMITING. If fully conscious, drink a quart of water. Get medical attention immediately. Never give anything by mouth to an unconscious person. If available give several glasses of milk. If vomiting occurs spontaneously, keep head below hips to prevent aspiration of liquid into the lungs.

An MSDS for this product is available through United's website, www.unitedlabsinc.com, providing 24 hour access. Please read the MSDS carefully and follow all directions when using or handling this product. Never reuse empty containers. Incompatible materials may adversely react.