

UNITED

L A B O R A T O R I E S

FOR URIC ACID SALT BUILD UP CREATES NO OFFENSIVE FUMES

GENERAL INFORMATION:

U/X is designed for regular maintenance of urinal lines. With its phosphoric acid base, the product works to eliminate the build-up of uric acid salts that cause lines to narrow and clog.

With regular use of **U/X**, clogs are minimized, lines run freely and odors are reduced.

U/X will not fume or cause any odor when working.

DIRECTIONS:

For auto-flush units, turn off the water before using **U/X**.

For regular maintenance, treat each urinal with 6-8 ounces of **U/X** and let sit overnight.

Problematic fixtures may need more frequent treatments.

DIRECCIONES:

Para unidades automaticas, cierre el agua antes de usar el producto **U/X**.

Para mantenimiento de diario, limpie cada orina con 6-8 onzas de **U/X** y deje senter el liquido toda la noche.

Muebles problameticos requieren limpieza mas seguido.

HMSI® III CODE: 0=MINIMAL 1=SLIGHT 2=MODERATE 3=SERIOUS 4=SEVERE PERSONAL PROTECTION INDEX: Gloves and Goggles	HEALTH	2
	FLAMMABILITY	0
	PHYSICAL HAZARD	0
	PERSONAL PROTECTION	n&p

United 877

U/X

Urinal Line Renovator

KEEP OUT OF REACH OF CHILDREN.

CAUTION

**SEE SIDE PANEL FOR ADDITIONAL
PRECAUTIONARY STATEMENTS.**

PRECAUCION AL USUARIO:

Si usted no puede leer Ingles, pregunte a alguien que le traduzca esta etiqueta para usted antes de uso.

Manufactured and Sold Exclusively By:
UNITED LABORATORIES, INC.
320 37th Avenue • St. Charles, IL 60174
1-800-323-2594 • www.unitedlabsinc.com

CAUTION:

Contains Phosphoric Acid CAS # (7664-38-2). Can cause severe burns to eyes. Protect eyes, skin and clothing when using this product or solutions made from it. This is an institutional and industrial cleaner and is not intended for home use.

DO NOT MIX United 877 WITH OTHER CLEANERS OR CHEMICALS.

It is good practice never to mix cleaners with other chemicals, as adverse chemical reactions can sometimes occur. Dilute **United 877** with water only.

EMERGENCY AND FIRST AID PROCEDURES:

EYES: Immediately flush with plenty of water for at least 15 minutes while holding eyelids open to ensure thorough rinsing of the entire surface of the eye and lids with water. Call a physician or poison center immediately.

SKIN: Wash with soap and plenty of water. Remove contaminated clothing and wash before reuse. If symptoms develop, call a physician or poison center.

INHALATION: Remove to fresh air. If symptoms develop, call a physician or poison center. If not breathing, give artificial respiration.

INGESTION: DO NOT induce vomiting. Call a physician or poison center immediately. If conscious, give several glasses of water to dilute. Never give anything by mouth to an unconscious person.

An MSDS for this product is available through United's website, www.unitedlabsinc.com, providing 24 hour access. Please read the MSDS carefully and follow all directions when using or handling this product. Never reuse empty containers. Incompatible materials may adversely react.