



UNITED

LABORATORIES



United 983

The innovative Inter-Core Technology combines the staying power of proven block technology with the instant concentrated dosage of a granular active.

- The core of **United 983** consists of 10 billion CFU/g count of a special bacterial blend that is released as a slug dose into the grease trap within minutes.
- The **I-C Grease Trap Maintainer** block is a special blend of bacteria. The 10 billion CFU/g block is designed to release its bacteria over an extended time (30-90 days) depending on loads.

Ideal for grease traps, this product provides an initial slug dose and then a continual source of bacteria to biodegrade grease and other organic wastes. The slow release shell of **I-C Grease Trap Maintainer** provides 30-90 days of grease and odor control.

- Easy installation with minimal ongoing attention.
- Eliminates odors.
- Earth Smart® Certified.
- Near neutral pH.
- Works at temperature range of 48°F to 110°F, with an optimum temperature range of 60°F to 96°F.

I-C Grease Trap Maintainer

with Inter-Core Technology
Patent Pending

KEEP OUT OF REACH OF CHILDREN.
CAUTION
SEE SIDE PANEL FOR ADDITIONAL PRECAUTIONARY STATEMENTS.

PRECAUCION AL USARIO:

Si usted no puede leer Ingles, pregunte a alguien que le traduzca esta etiqueta para usted antes de uso.

Sold Exclusively By:
UNITED LABORATORIES, INC.
320 37th Avenue • St. Charles, IL 60174
1-800-323-2594 • www.unitedlabsinc.com

DIRECTIONS FOR USE:

I-C Grease Trap Maintainer should be suspended in the trap so the block is just under the grease cap. Apply one 2 lb. block for every 350 gallons capacity. If capacity is over 500 gallons, spread the blocks out in different sections of the trap. For heavy loading, add one block of United 856 BIO-ACCEL in the first chamber with **United 983**.

EMERGENCY AND FIRST AID PROCEDURES:

EYES: Flush eyes with cool water for at least 15 minutes while keeping eyelids open. If irritation persists, seek medical attention.

SKIN: Wash with soap and water. Launder clothing. If irritation or redness persists, seek medical attention.

INHALATION: Not applicable.

IF SWALLOWED: Thoroughly rinse mouth with water. Drink one or two glasses of water. Slight gastrointestinal discomfort may occur.

An MSDS for this product is available through United's website, www.unitedlabsinc.com, providing 24 hour access. Please read the MSDS carefully and follow all directions when using or handling this product.

HMIS® III CODE: 0=MINIMAL 1=SLIGHT 2=MODERATE 3=SERIOUS 4=SEVERE PERSONAL PROTECTION INDEX: Glasses and Gloves	HEALTH	0
	FLAMMABILITY	0
	PHYSICAL HAZARD	0
	PERSONAL PROTECTION	B