



# UNITED

LABORATORIES

### GENERAL INFORMATION:

**United 53 Defoamer** is a concentrated, Industrial silicone-based defoamer. Use **United 53 Defoamer** to knock down detergent foam in:

- Wastewater influent
- Wastewater effluent
- Wastewater aeration areas
- Chlorine contact chambers
- Spas, hydrotanks and decorative fountains
- Cooling tower and boiler descaling

**United 53 Defoamer** is non-corrosive, non-flammable, and non-toxic. **United 53 Defoamer** should not be used for "chocolate" foam. **United 594 Slime and Grease Cutter** is recommended for this problem.

### DIRECTIONS FOR USE:

**United 53 Defoamer** is a concentrate and should be diluted with five to ten parts of water for spray application. Use a pump-up sprayer, such as the **United A062** to apply to small areas. For larger areas, metered pumping equipment is satisfactory. **United 53** can also be dripped into influent wells.

As little as one half of one part per million of **United 53 Defoamer** is frequently sufficient to knock down detergent foam in wastewater aerators, tanks, streams, and holding ponds. To defoam decorative fountain displays that have been "soaped" by vandals, add one gallon of **United 53 Defoamer** per 100 gallons of capacity. This usage level may be adjusted depending on the amount of soap or detergent that has been dumped into the fountain.

## United 53

# Defoamer For Municipal And Industrial Applications

**KEEP OUT OF REACH OF CHILDREN.**

### CAUTION

**MAY BE HARMFUL IF SWALLOWED.  
SEE SIDE PANEL FOR ADDITIONAL  
PRECAUTIONARY STATEMENTS.**

#### PRECAUCION AL USUARIO:

*Si usted no puede leer Ingles, pregunte a alguien que le traduzca esta etiqueta para usted antes de uso.*

**UNITED LABORATORIES, INC.**  
320 37th Avenue • St. Charles, IL 60174  
1-800-323-2594 • [www.unitedlabsinc.com](http://www.unitedlabsinc.com)

### CAUTION: EMERGENCY AND FIRST AID PROCEDURES:

**EYES:** Flush with cool water for at least 15 minutes. If irritation persists call a physician or poison control center.

**SKIN:** Wash with soap and water. Call a physician if irritation develops.

**INHALATION:** Remove to fresh air. Apply CPR if necessary. Call a physician if irritation persists.

**IF SWALLOWED:** Call a physician.

An MSDS for this product is available through United's website, [www.unitedlabsinc.com](http://www.unitedlabsinc.com), providing 24 hour access. Please read the MSDS carefully and follow all directions when using or handling this product. Never reuse empty containers. Incompatible materials may adversely react.

<b>HMIS® III CODE:</b> 0=MINIMAL 1=SLIGHT 2=MODERATE 3=SERIOUS 4=SEVERE <b>PERSONAL PROTECTION INDEX:</b> Glasses and Gloves	HEALTH	0
	FLAMMABILITY	0
	PHYSICAL HAZARD	0
	PERSONAL PROTECTION	B