

SMART SOLVE® Degreaser Wipes clean up grease, grime and oil from equipment and hard surfaces. This patented, innovative degreaser targets many tough to handle issues, while being safer in use for both you and the environment.

SMART SOLVE® is:

- Earth Smart® Certified
- Bio-Based - From Vegetable Extract
- NPE-Free • VOC-Free
- Petroleum Distillate Free
- Non-Toxic, Non-Caustic, Non-Corrosive, Non-Acid
- Free of Chlorinated Hydrocarbons



NPE Free

SMART SOLVE® Degreaser Wipes work fast to loosen, dissolve and lift:

- Dirt • Oil • Grease • Tar
- Glues • Adhesives • Tape Residue and more...

Safe for use on any metal surfaces and many other hard, non-porous surfaces. May be used on fiberglass, Plexiglas and any plastic surfaces, but it is recommended to limit contact time to 10 minutes. Do not use on hard, clear polystyrene surfaces. This product may soften or craze certain plastics. If surface compatibility is uncertain, test in a small inconspicuous area before use. Do not use on asphalt surfaces.

DIRECTIONS:

Pull a pre-moistened wipe from the canister and applying light pressure, wipe over the area to be cleaned. For heavier build-up, use the abrasive side of the wipe to make clean-up easier. After area is cleaned with **SMART SOLVE®**, use a clean, damp cloth to wipe away any remaining dirt or product.

Cleaning Hands: As you clean your tools and equipment with these wipes, you can even use them to break through the tough dirt and grease on your hands. If product residual remains on hands, rinse thoroughly with water and dry with a clean cloth.

PRECAUCION AL USARIO: Si usted no puede leer Ingles, pregunte a alguien que le traduzca esta etiqueta para usted antes de uso.

Manufactured and Sold Exclusively By:
UNITED LABORATORIES, INC.
 320 37th Avenue • St. Charles, IL 60174
 1-800-323-2594 • www.unitedlabsinc.com



United 607

SMART SOLVE®



Degreaser Wipes

Patent No. 7588646 Patent No. 7846267

KEEP OUT OF REACH OF CHILDREN.

CAUTION
SEE SIDE PANEL FOR ADDITIONAL PRECAUTIONARY STATEMENTS

Contains: 70 – 9 1/2" x 12" Wipes

DIRECTIONS FOR DISPENSING:

Remove lid. Pull towels up from the center of the roll and twist into a point. Push twisted towel through center of notched opening in the underside of the lid. Replace lid, making sure lid fits securely. Pull out wipe at a 90 degree angle and tear off at perforation. Dispose of properly. Remaining wipes feed automatically for next use. Always reseal hinged cap to insure against moisture loss and contamination.



HANDLING AND STORAGE: Keep container tightly closed when not in use. Store in a cool, dry, area and prevent from freezing. Allow to sit at room temperature before using product to ensure best product performance.

PRECAUTIONS: Avoid contact with eyes. Do not ingest.

EMERGENCY AND FIRST AID PROCEDURES:

EYES: Immediately flush eyes with water for at least 15 minutes while holding eyelids open. If irritation persists, get medical attention.

SKIN: Wash with soap and plenty of water. If symptoms develop, seek medical attention.

INHALATION: Remove to fresh air. If symptoms develop, seek medical attention. If not breathing, give artificial respiration.

INGESTION: DO NOT induce vomiting. Get medical attention immediately. If vomiting occurs, have victim lean forward to reduce risk of aspiration.

An MSDS for this product is available through United's website, www.unitedlabsinc.com, providing 24 hour access. Please read the MSDS carefully and follow all directions when using or handling this product. Never reuse empty containers. Incompatible materials may adversely react.

HMS® III CODE: 0=MINIMAL 1=SLIGHT 2=MODERATE 3=SERIOUS 4=SEVERE PERSONAL PROTECTION INDEX: None	HEALTH	1
	FLAMMABILITY	1
	PHYSICAL HAZARD	0
	PERSONAL PROTECTION	-